



EUROMATIK.NET

Using the osf communication server


You can reach the osf communication server at <http://devices.osf.de>.




As a new user, you must first register:




After registering, you can log in and then enter your new device in your user profile:



You can find the DEVICE ID of your device on the device information page on the control panel of the device:



Your device then appears in your device overview and can be operated using the communication server:



To use the communication server, the Internet connection via communication server must be activated (factory setting):

