

Supplement to the installation instructions

Filter-Control-Plus

CE


Mains connection when using a Sta-Rite Supermax VS pump

A Sta-Rite Supermax VS pump can be connected directly to the Filter-Control-plus. The speed control is connected to terminals 10-15.

The power supply for the pump must be provided separately from the mains and cannot be provided by the Filter-Control-plus.

A bridge must be inserted between the two terminals 1 and 2 (winding protection contact).

The operating instructions for the pump must be observed!



OSF Hansjürgen Meier

Elektrotechnik und Elektronik GmbH & Co KG
Eichendorffstraße 6
D-32339 Espelkamp
E-Mail: info@osf.de
Internet: www.osf.de

Subject to changes **OSF** 11/2020